



US Army Corps of Engineers®

Ice Harbor Lock and Dam

Boat Restricted Zones

- Buoy - Orange
- Buoy - Red
- Boat Ramp
- Lock Call Box
- Parking
- Toilet
- Visitor Center
- No Boats
- No Fishing
WDFW Regs



The U.S. Army Corps of Engineers assumes no liability for correctness or accuracy, and reserves the right to correct, update, or modify geospatial data and/or products without notification.

Prepared March 13, 2013

(5534) (5) At Ice Harbor Lock and Dam. The waters restricted to all vessels, except Government vessels, are described as all waters within a distance of about 800 yards upstream of the dam lying south of the navigation lock and bound by the line commencing at the upstream end of the guidewall, and running a direction of $91^{\circ}10'$ true for a distance of 575 yards; thence $162^{\circ}45'$ to the south shore, a distance of about 385 yards. The downstream limits commencing at the downstream end of the guidewall; thence to the south shore, at right angles and parallel to the axis of the dam. Signs designate the restricted areas.

SNAKE RIVER - where the river coincides with the boundary between Washington and Idaho, the license of either state is valid. Anglers must comply with the laws of the state issuing the license. An angler licensed only in Idaho may not fish on the Washington shore or in Washington sloughs or tributaries. An angler fishing is restricted to one daily limit even if licensed by both states.

Snake River Confluence Protection Area - waters of the Columbia River from the railroad bridge between Burbank and Kennewick upstream approximately 2.1 miles to the first powerline crossing upstream of the navigation light on the point of Sacajewea State Park: Daily limits, seasons, size restrictions, and gear restrictions are the same as those in the adjacent area of the Snake River

CLOSED WATERS - within 400' of the base of any dam; within a 400' radius around the fish ladder entrance at Lyons Ferry Hatchery; within a 200' radius upstream of the fish ladder exit above Lower Granite Dam; and within an area 1,200' downstream from the base of the west lock gate at Little Goose Dam on the south bank of the Snake River and 100' out into the river from said river bank.

- Below Ice Harbor Dam (640)
- Ice Harbor Dam to Lower Monument Dam (642)
- Lower Monument Dam to Little Goose Dam (644)
- Little Goose Dam to Lower Granite Dam (646)
- Lower Granite Dam to Washington/Idaho state line in Clarkston (648)
- Upstream of the Washington/Idaho state line in Clarkston (650)

TROUT	June 16-Aug. 31	Min. size 10". Daily limit 6. Release all STEELHEAD.
TROUT	Sept. 1-Mar. 31	Min. size 10". Daily limit 6. Up to 3 hatchery STEELHEAD may be retained. Barbless hooks required when fishing for STEELHEAD.
CHANNEL CATFISH	Year-round	No min. size. No daily limit.
WALLEYE	Year-round	No min. size. Daily limit 10. Up to 5 over 18" and only 1 over 24" may be retained.
Other Game Fish	Year-round	Statewide min. size/daily limit.

From mouth to Ice Harbor Dam.

STURGEON May 1-July 31 **CLOSED** to fishing for STURGEON from Ice Harbor Dam downstream 1.5 miles to the downstream end of Goose Island.

STURGEON	Feb. 1-July 31	Min. size 43" fork length. Max. size 54" fork length. Daily limit 1.
STURGEON	Aug. 1-Jan. 31	Catch-and-release.

From Ice Harbor Dam to Oregon border.

STURGEON	Year-round	Min. size 43" fork length. Max. size 54" fork length. Daily limit 1. Catch-and-release for all STURGEON in waters upstream of Lower Granite Dam (includes all tributaries of the Snake River above this point).
----------	------------	---

Col. R. Salmon/Steelhead Endorsement (p. 16)

A Washington license is required to fish downstream Snake R. (west of the state boundary line).

An Idaho license is required to fish in the Clearwater R.

An Idaho or Washington license is required to fish the Snake R. ID/WA boundary waters.

