

Sediment Surrogates for the Clearwater and Snake Rivers

Basic Concept

- Need for indirect, continuous measurements of sediment
- Can we relate “surrogate” parameters to sediment?
- Promising techniques:
 - Backscatter from acoustic velocity meters
 - Laser diffraction
 - Turbidity
- May work well when sediment – flow relationship is unstable





Photo courtesy of Sontek

Example Data Collection System



Courtesy of Eduardo Patino, USGS Florida

Surrogate Technologies

■ Acoustics

- Pros: Profiling, no biofouling
- Cons: Need for multiple instruments in some cases, insensitivity at low concentrations, difficult data corrections

■ Laser Diffraction


- Pros: Real-time particle size and SSC
- Cons: Biofouling, requires dilution $> 3,000$ mg/L, point measurement

■ Turbidity

- Pros: Well-tested, relatively cheap and easy
- Cons: Biofouling, calibration needs, point measurement

Snake and Clearwater Rivers

- *Purpose:* Study sediment sources as part of sediment management program for Lower Granite Reservoir
- Installed surrogate gages in May 2008
- Clearwater River – “Supergage”
 - Acoustics, turbidity, laser
 - Variable grain size distribution
- Snake River – Turbidity only
 - Mostly silt



Installation



Clearwater Surrogates



ACOUSTIC FREQUENCY VS PARTICLE SIZE

ACOUSTIC FREQUENCY	Best for:
500 kHz	Coarse sand
1.5 mHz	Medium sand
3 mHz	Silt



Lower Frequency
Appropriate
for Larger Particle Sizes

↑ Fine Mtls = ↑ Backscatter Attenuation
↑ Coarse Mtls = ↑ Backscatter

LISST Streamside

Particle Size Analysis Report

Sample No.: 5386-1

Date: Oct. 21, 2003



Customer Sample Description: 143 B

Report Prepared for:

ACME, Inc.

123 Main ST

Walla Walla, WA



Computed Statistics

D10 = 2.23 Specific Surface Area = 0.09 m^2/g
 D50 = 1.90
 D90 = 21.56
 Dmean = 18.62

Size (microns)	Volume Conc. (%)	Cumulative Volume
1.36	2.34%	2.34%
1.60	2.59%	4.93%
1.89	2.19%	7.12%
2.23	2.32%	9.43%
2.63	2.33%	11.76%
3.11	3.44%	15.20%
3.67	2.23%	17.43%
4.32	4.25%	21.67%
5.11	4.40%	26.07%
6.03	4.83%	30.90%
7.11	4.96%	35.86%
8.39	3.40%	40.26%
9.90	3.75%	44.01%
11.69	3.14%	47.15%
13.79	3.36%	50.51%
16.27	3.78%	54.29%
19.29	3.91%	58.20%
22.96	5.20%	63.40%
28.74	5.12%	68.52%
34.56	3.67%	72.19%
41.24	2.81%	75.00%
49.95	2.21%	77.21%
59.60	1.55%	78.76%
71.20	1.07%	79.83%
85.22	3.72%	83.55%
102.27	3.46%	87.01%
122.87	3.20%	90.21%
146.64	3.18%	93.39%
175.26	3.25%	96.64%
209.02	3.46%	100.00%
250.14	3.72%	100.00%

SEQUOIA


Sequoia Scientific, Inc.
 2710 Roberts Road, Suite 107
 Bellevue, WA 98005
 Tel: 425.867.2404
 Fax: 425.867.5508

Comments: Dry sample was mixed with filtered water. Sample was disaggregated in ultrasonic bath for 5 minutes before analyzing.

Analysis Performed by: _____


Date: _____

Analysis performed using laser diffraction techniques as described in AWWA Standard No. 2500D. Instrumentation calibrated using NIST traceable standard particles.




PRELIMINARY RESULTS: Clearwater River


0.5MHz Acoustics - Relative Backscatter




3MHz Acoustics - Relative Backscatter




Turbidity



LISST 100X Laser Diffraction



Clearwater River: Acoustic Predictions of SS Load




Preliminary Summary - Clearwater


Surrogate	R ²	Average % Difference From Measured
3MHz Backscatter - SSC	0.994	+11%
0.5MHz Backscatter - SSC	0.984	-0.3%
3MHz Attenuation – Silt/Clay Fraction	0.921	+29%
0.5MHz Backscatter – Sand Fraction	0.985	
Turbidity - SSC	0.836	-12%
LISST 100X - SSC	0.866	-12%
LISST Streamside - SSC	TBA*	TBA
1970's Sediment Curve	NA	-103%
2008 Discharge - SSC	0.866	+23%

[illegible][illegible][illegible]

Acoustics Profiling Range



Effect of Lapwai Inflow?



Snake River




YSI Sonde with Turbidity Probe




PRELIMINARY RESULTS:

Snake River


Turbidity



Snake River Turbidity and Flow



Snake River: Turbidity Predictions of SS Load



Preliminary Summary - Snake

Surrogate	R ²	Average % Difference From Measured
Turbidity - SSC	0.956	-2.3%
1970's Sediment Curve	NA	-5.2%
2008 Discharge - SSC	0.830	+51.4%

Overall Implications

- Increased accuracy?
- Greater temporal resolution of concentrations and loads
- Reduced sampling frequency
- Reduced O&M costs
- Safer
- Potential for real-time SSC estimates




Example: Near-Real-Time Sediment

Suspended sediment concentration, Filtered, milligrams per liter

Most recent instantaneous value: 20.3 11-04-2008 14:00

USGS 01372058 HUDSON RIVER BELOW POUGHKEEPSIE NY




[Create presentation-quality graph](#)

Suspended sediment discharge, Filtered, tons per day

Most recent instantaneous value: 1,080 11-04-2008 14:00

USGS 01372058 HUDSON RIVER BELOW POUGHKEEPSIE NY



Courtesy: USGS New York, Lower
Hudson River Project

Project Website

http://id.water.usgs.gov/projects/surrogate_sediment/



[USGS Home](#)
[Contact USGS](#)
[Search All USGS](#)

Idaho Water Science Center

Search Idaho



Site Contents

[Home](#)
[About Us](#)
[Data for Idaho](#)
[Recent Idaho Publications](#)
[USGS STUDIES IN IDAHO](#)
[National Water Programs](#)
[Outreach and Education](#)
[Website Information](#)

External Resources

[USGS Publications Warehouse](#)
[NWIS Web](#)
[Current Conditions](#)

Suspended Sediment Surrogate Technology Study on the Clearwater and Snake Rivers

Conducted in cooperation with [US Corps of Engineers](#)

[Home](#) > [Studies in Idaho](#) > [Suspended Sediment Surrogate Technology](#)

Data

Data from this study will be used to quantify and predict relative sediment contributions from the Snake and Clearwater River basins to the Lower Granite Reservoir. If relationships can be successfully developed between sediment concentrations and data from one or more surrogate technologies, predicted sediment concentrations will be made available on the web on a near real-time basis. As a result, sediment data would be available at a much higher temporal resolution than was previously available through the collection of periodic samples.

Clearwater River near Spalding, Idaho—[13342500](#)

SNAKE RIVER AT ANATONE, Washington—[13334300](#)

See these sites on the [study area map](#).

About this Study

[Introduction](#)
[Study Area Map \(new window\)](#)
[Methods](#)
[DATA](#)
[Publications](#)
[Contacts](#)
[To Learn More](#)



Future Plans

- Proposed: acoustics on the Snake River
- Extend mounts
- Collect more information at mid- and high-flows
- Quantify cross-channel variability
- Continue to interpret data
- Journal article planned for FY2010
- Possible: near-real-time SSC



Questions?